


## CA3 Concrete Anchor Catalog Pg. 6



(1) With a masonry bit, drill a 3/8" diameter x 1-7/8" deep hole. Will secure in materials down to 1" thick but will not have the strength of mounting in materials 1-7/8" and thicker.

(2) Insert the HD-CA3 anchor completely into the hole till the washer and nut are against the concrete. The red nylon compression ring prevents the anchor from rotating during installation.

(3) Using the washer and nut supplied on the anchor, tighten the anchor until it is completely secure in the concrete. NOTE: Do not attempt to secure the anchor using your aluminum parts. Cosmetic damage to the parts is likely and the anchor will not be as well secured.

(4) Remove the nut and washer and mount your StandOff Systems™ parts. The parts used, in this example a 1" x 1" barrel, should be well tightened to retain the hold of the anchor. The rest of your parts should be attached after the piece mounting on the anchor stud is tight.