


## HD-CA4 Concrete Anchor



(1) With a masonry bit, pre-drill a 1/4" diameter hole x 1-1/2" deep in concrete, cinder block or other masonry surface.

(2) With a hammer, lightly tap the lead anchor into the surface until the head is as flush as possible. Be careful not to deform the metal anchor or wall surface.

(3) Screw the appropriate #8 Screw or Combination Screw into the center of the installed anchor.

(4) Attach the desired **Gyford StandOff Systems®** parts needed for the application to complete the assembly.

**IMPORTANT**

*These HOW TO instructions are GUIDELINES ONLY. Your installation may be different from those shown here. NO SAFETY GUARANTEE is expressed or implied in any installation unless such guarantee is provided IN WRITING by Gyford Productions on installations that Gyford Productions does. It is the responsibility of the INSTALLER and/or END USER to ensure that the parts and materials used in any installation are specified and engineered to meet the demands of their intended purpose.*

*Call 775.829.7272 to speak with our knowledgeable Client Solutions Specialists about your installation.*